

BLACK+DECKER®

Model: GC3100B-LA

Jarra de repuesto para 12 tazas*

Para la mayoría de las cafeteras BLACK+DECKER®

de 12 tazas* incluyendo: CM2020, CM4000, DLX1050, CM0940, CM1110, CM1060, CM1160, CM1100, CM1200, CM4100, CM2030, CM1070, CM1050, BCM1410, CM4200, CM1231, CM1331

Note: El número de la tapa está grabado en la parte inferior de la tapa, en la parte frontal.

1. Tapa 1 (part no. GC3100-01) fits: CM2020, CM4000, DLX1050, CM0940, CM1110, CM1060, CM1160, CM1100, CM1050, CM1200
2. Tapa 2 (part no. GC3100-02) fits: CM4100, CM2030, CM1070
3. Tapa 3 (part no. GC3100-03) fits: BCM1410, CM4200, CM1231, CM1331

IMPORTANTE: ¡LAVAR LA JARRA Y LAS PIEZAS ANTES DE SU PRIMER USO!

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

- Mantenga la tapa en la jarra cuando esté en uso.
- La jarra nunca debe usarse sobre una estufa.
- No limpie la jarra con limpiadores abrasivos, lana de acero u otros materiales abrasivos.
- No coloque una jarra caliente sobre una superficie fría o húmeda.
- No use la jarra si el vidrio está rajado o tiene un mango flojo o debilitado.
- Pueden producirse quemaduras si se quita la tapa durante el ciclo de preparación.

TRATAR LA CARAFE CON CUIDADO

Una jarra dañada puede provocar posibles quemaduras por líquidos calientes. Para evitar romperse:

- No permita que se evapore todo el líquido de la jarra mientras está en la placa "Keep Hot", ni caliente la jarra cuando esté vacía.
- Deseche la jarra si está dañada de alguna manera. Una astilla o grieta podría resultar en rotura. Tenga cuidado al manipular y desechar una jarra dañada.
- Nunca use estropajos o limpiadores abrasivos; rayarán y debilitarán el vidrio.
- No coloque la jarra sobre o cerca de un quemador de gas o eléctrico caliente, en un horno caliente o en un horno de microondas.
- Evite el manejo brusco y los golpes fuertes.

QUITAR LA TAPA DE LA JARRA

1. Abra la tapa de la jarra.
2. Con una mano en el asa y la otra en la parte posterior de la tapa, desbloquee con cuidado las pestañas de la tapa de las muescas en el mango.

Tip: si tiene problemas para desbloquear las pestañas al mismo tiempo, primero desbloquee una pestaña y luego la otra.

COLOCACIÓN DE LA TAPA A LA JARRA

1. Coloque la tapa de la jarra deseada encima de la jarra.
2. Sosteniendo la jarra por el asa con una mano, use la otra para presionar hacia abajo la parte posterior de la tapa para bloquear las pestañas de la tapa en las muescas del asa.

**Una taza equivale a aproximadamente 5 onzas (varía de acuerdo al método de preparación utilizado)

BLACK+DECKER and the BLACK+DECKER logos are trademarks of The Black & Decker Corporation, used under license by Spectrum Brands, Inc. for its manufacturing and sale of this product. All rights reserved.

© 2021 Spectrum Brands, Inc. All rights reserved.
Spectrum Brands Inc., Middleton, WI 53562

T22-9002418
2021/06

Made in China



BLACK+DECKER®

Model: GC3100B-LA

12-Cup* Replacement Carafe

Fits many BLACK+DECKER® 12-cup coffeemakers, including:
CM2020, CM4000, DLX1050, CM0940, CM1110, CM1060,
CM1160, CM1100, CM1200, CM4100, CM2030, CM1070, CM1050,
BCM1410, CM4200, CM1231, CM1331

Note: The lid number is embossed on the underside of the lid, near the front.

1. Lid 1 (part no. GC3100-01) fits: CM2020, CM4000, DLX1050, CM0940, CM1110, CM1060, CM1160, CM1100, CM1050, CM1200
2. Lid 2 (part no. GC3100-02) fits: CM4100, CM2030, CM1070
3. Lid 3 (part no. GC3100-03) fits: BCM1410, CM4200, CM1231, CM1331

IMPORTANT: WASH CARAFE BEFORE FIRST USE!

IMPORTANT SAFEGUARDS

- Keep the lid on the carafe when in use.
- Carafe must never be used on a range top.
- Do not clean the carafe with abrasive cleansers, steel wool or other abrasive materials.
- Do not set a hot carafe down on a wet or cold surface.
- Do not use the carafe if the glass is cracked or has a loose or weakened handle.
- Scalding may occur if the lid is removed during the brewing cycle.

TREAT CARAFE WITH CARE

A damaged carafe may result in possible burns from hot liquids. To avoid breaking:

- Do not allow all liquid to evaporate from the carafe while on the "Keep Hot" plate, nor heat the carafe when empty.
- Discard the carafe if damaged in any manner. A chip or crack could result in breakage. Use caution when handling and discarding a damaged carafe.
- Never use abrasive scouring pads or cleansers; they will scratch and weaken the glass.
- Do not place the carafe on or near a hot gas or electric burner, in a heated oven, or in a microwave oven.
- Avoid rough handling and sharp blows.

REMOVING THE CARAFE LID

1. Open the carafe lid.
2. With one hand on the handle and the other on the back of the lid, carefully unlock the tabs on the lid from the notches on the handle.

Tip: If you are having trouble unlocking the tabs at the same time, unlock one tab first, then the other.

ATTACHING THE CARAFE LID

1. Place desired carafe lid on top of the carafe.
2. Holding the carafe by the handle with one hand, use the other to press down on the back of the lid to lock the lid tabs onto the notches on the handle.



*One cup equals approximately 5 oz. (varies by brewing technique)

BLACK+DECKER and the BLACK+DECKER logos are trademarks of The Black & Decker Corporation, used under license by Spectrum Brands, Inc. for its manufacturing and sale of this product. All rights reserved.

© 2021 Spectrum Brands, Inc. All rights reserved.
Spectrum Brands Inc., Middleton, WI 53562

T22-9002418
2021/06

Made in China